


# Item # : BQSPIN

## Assembly Instructions



Walker  
Edison®


Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkerredison.com](http://www.walkerredison.com)

Revised 06/2020


Copyright © 2018, by Walker Edison Furniture Co., LLC. All rights reserved.

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product .



- VI. Power tools should not be used to assemble this product .





















# Parts List



- Part 1: Spindle
- Part 2: Slat
- Part 3: Legs
- Part 4: Cross bar
- Part 5: Bracket
- Part 6: Top rail
- Part 7: Bottom rail
- Part 8: Front rail
- Part 9: Back rail
- Part 10: Right side rail
- Part 11: Left side rail
- Part 13: Support beam
- Part 14: Spindle Support Rail Lower
- Part 15: Feet

# Hardware List



A		Ø7x70 mm	Bolt Black	16 pcs
B		Ø3.5x30 mm	Screw Black	56 pcs
C		Ø3.5x30 mm	Screw Black	22 pcs
D		Ø7x50 mm	Bolt Black	08 pcs
E		Ø10x40 mm	Wood dowel	16 pçs
F		Ø6x30 mm	Wood dowel	04 pcs
G		Ø 1/4"x60 mm	Bolt Black	06 pcs
H			Washer	06 pcs
I			Nut	06 pcs
J			Hex key	02 pcs
K			Wrench	01 pcs
L			Spacer	02 pcs
M		Ø1/4"X50mm	Screw Black	04 pcs
N		Ø1/4 "	Union Screw	04 pcs
O		Ø4.0x40 mm	Screw	06 pcs
P		Ø3.5x20 mm	Screw	11 pcs
Q		50x50 mm	Metal Plate Connector	02 pcs




Philips head screwdriver required for assembly  
(not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*



# Step 1


E	
F	



Insert wood dowels (E) into parts (4,5,8,9) dowels and dowels (F) into parts (13)



# Step 2


A	 70mm
J	



Attach legs (3) to cross bar (4) using bolt (A) and hex key (J)


## Step 3

A	 70mm
J	



Secure part (4) to part (8,9) using bolt (A) and hex key (J)

## Step 4



Connect parts (10,11) to parts (8,9)




## Step 05

A



70mm

J





Secure parts (10,11) to parts (8,9) with Screw (A).

## Step 06

O




40mm




Secure part (8,9) to part (11,10) using screw (O)

## Step 07



Attach legs (15) to frame parts (10,11) using screw (M) and Union Screw (N). Union Screw (N) should be on the inside of the bed frame, with screw (M) on the outside of the leg. Tighten by using with hex key (J) on both ends of the screw at the same time. The use screw (D) and hex key (J) to secure legs (15).

## Step 08



Secure feet to frame using screw (C).





## Step 09

P

20mm



Q




Attach the metal connector plate (Q) to the 2 corners of the bed with screw (P)

## Step 10



O


40mm



Connect parts 5 to part 7. Note the drawing for location of pocket hole. Secure parts (5) to part (7) using screw (O).



## Step 11


D	 50mm
J	



Attach parts (13) to part (6) using bolt (D) and hex key (J)

## Step 12



D	 50mm
J	



Start at one end of the headboard. Fit large spindle (13) into part (5) and secure with screw (D) and hex key (J).

# Step 13

C




Insert the Spindle (Part 1) underneath and use Screw (C) to connect to Part 6.

# Step 14


Spindle

B



Bar


P



Insert Headboard slat (14) on part (7), with 3 screw ( P),  
secure more 4 Screw (B) in Spindles (1)

# Step 15


E




insert Wood Dowel 2x (E)

# Step 16



B



L



Start With Space



Using the spacer provided (N), place the bed slats (2) evenly along the bed rails (10,11). Attach slats (2) to side rails (10,11) and center rail (4) using screw (B). Note- Avoid gaps between the end of each slat and the side rails by adding pressure to the side rails (10,11) to push them together while securing the slats.

# Step 17

G



60mm


H




I



J




K



First make sure Wood dowel inserted on the frame (7) is aligned on holes to part(9)  
 Attach the base of the headboard (7,5) to the frame (9)  
 using bolt(G), washer(H) , and nut (I) . Tighten using both the hex key (J) and wrench (K).

## Step 18



# Final Assembly.